


Upgrade a DC-Digital Network Clock's Firmware



These instructions pertain to DC-Digital network clocks


1. **[customer name]_APP.s19** We will email you this file in which to update the clock with.
2. **Download the autoupdate application from the DC-Digital website:** It can be found on the same page where you found this document – or located here:
<https://dc-digital.com/wordpress/2016/07/ntp-auto-update-exe-file/>
3. **Load the autoupdate application:** on a computer that can see the DC-Digital clocks on your network. Run the application.



Once *autoupdate* is running, select **Find**.

This will list all the DC-Digital network devices present on your network.


4. **Select the device you wish to update.**



If you do not see the clock listed, make sure the device is plugged into your network and powered on, then select **Search Again**

Highlight the clock you want to update and select **OK**


5. **Load the file in which to update.** This will always be an APP.s19 file.



Use **Browse** to navigate to where the APP.s19 file DC-Digital has emailed to you is located – and select that file.

Once the file is selected – click on **Update** to perform the software update.

6. The “Programming Complete without Error” message should pop up.



7. Correct time in less than a minute. The DC-Digital device should now query the Default NTP Server Time.NIST.Gov, and the clock should update with the correct time in less than a minute. If the device fails to update with the correct time, cycle the power to the clock.

If you have any questions or concerns with this or any DC-Digital product, please feel free to contact us!

Phone: 937-746-9750

Web: www.dc-digital.com

Email: info@dc-digital.com